

# Computer Know How Series

Presented by Adam Lacey (*Applications Etc.*) 916-813-7819

Apple iDevices (2007-current) – Thursday June 9<sup>th</sup> 2016 @ 2pm

- 1) Device Orientation (know your device)
  - a. Physical Device
    - i. Buttons/Switches – Home/Touch ID Sensor (front bottom), Sleep/Wake (top or right side), Volume (top left), Silence/Rotate Lock (top left)
    - ii. Ports/Sensors – Charge/USB Port (bottom), Mic (bottom, top, back), Speaker (front, bottom), Cameras (front, back), Cellular/WiFi/Bluetooth/GPS Antennas, Proximity Sensor (front), 3-Axis Gyroscope (front), Ambient light sensor (front), Accelerometer, Barometer
  - b. Operations System (OS) and Updates
    - i. Operating Systems (Current iOS 9.x.x)
    - ii. Updates (iTunes [Alpha], Device (Setting > General, Software Update[Delta])
  - c. Differences between iDevices (iPhone, iPod Touch, iPad, iPad Pro)
    - i. Smartphone, MP3 Player, Tablet
  - d. Sleep/Wake
    - i. Unlock (Button > Swipe) or Finger Print Sensor (Home Button)
    - ii. Lock & Auto Lock Options (passcodes)
  - e. Identify your Device (Settings > General > About)
    - i. Name, Network (Cell), Capacity, Version (iOS), Model
- 2) Connectivity
  - a. Cellular Carriers (AT&T, Verizon, Sprint, T-Mobile)
  - b. Cellular Voice and Data (2G, 3G, 4G HSPA+, 4G LTE)
  - c. WiFi (\_\_\_\_\_ ) (Local Wireless Network)
  - d. GPS (\_\_\_\_\_ ) (Receive Only)
  - e. NFC (Near Field Communication) (iPhone 6 and newer)
- 3) Gestures
  - a. Swipe(s) (←↑→↓), Tap, Tap & Hold, Double Tap, Double Finger Tap, Pinch (in/out)
  - b. 4 Finger Swipe, 5 Finger Pinch (iPad iOS 5+)
  - c. 3D Touch - Push and Pop (iPhone 6s & iPhone 6s Plus)
  - d. App Switcher (Tap and Hold left side of Screen then Swipe Right)
- 4) Notifications/Badges (Push, Alert, Banner)
  - a. Notification Center (iOS 5 or greater) & Control Center (iOS 8 or greater)
  - b. Phone, Messages & Mail
  - c. App Store Updates
  - d. 3<sup>rd</sup> party Push Notifications
- 5) Limitations
  - a. Hardware (no user replaceable)
    - i. Battery (Not User Replaceable), Screen Replacement (glass touch sensor and display)
    - ii. Button Failure/Replacement (mechanical)
  - b. Software
    - i. iOS (Apple Restrictions/Limitations)
    - ii. No Adobe Flash Player (mostly replaced by HTML5)

- iii. File Storage (USB, WiFi, Apps)
- iv. 3<sup>rd</sup> party apps (only from App Store)
- v. Jailbreaking (3<sup>rd</sup> party App Store)

6) Apps

- a. OS (Settings, Spotlight Search, Siri [Voice Assistant] ["Hey Siri" hands free])
- b. Phone (iPhone only) & Contacts
- c. Messages (SMS, MMS & iMessage)
- d. Mail, Calendar & Reminders
- e. Camera & Photos (live photos, videos, collections)
- f. Safari
- g. Maps (demo - 3D Touch, Gestures)
- h. Music & Videos
- i. Health
- j. Wallet/Apple Pay (uses NFC for secure transactions)
- k. 3<sup>rd</sup> Party (depends on user usage) (Apple App Store)

7) iCloud (Sync, Security, Backups)

- a. Calendar, Contacts, Mail, Reminders
- b. Photos (sharing)
- c. Documents, Notes, Bookmarks
- d. Backups (5GB Free and Purchased Capacities)
- e. Find my iPhone/iDevice (Battery Level, Play Sound, Lost Mode, Erase)

8) Troubleshooting & Maintenance

- a. App Termination
- b. Restarting
- c. Cases & Screen Protectors

9) Links

- a. Apple - <http://www.apple.com/iPhone> or [iPod](http://www.apple.com/iPad) or [iPod](http://www.apple.com/iPod)
- b. Getting Started Guide - <https://support.apple.com/en-us/HT202033>
- c. iPhone User Guide - <https://support.apple.com/en-us/HT202033>
- d. iPad User Guide - <https://help.apple.com/ipad/9/>
- e. iPod Touch Guide - <https://help.apple.com/ipod-touch/9/>
- f. 3d Touch - <https://developer.apple.com/ios/3d-touch/>
- g. History of iPhone - [https://en.wikipedia.org/wiki/History\\_of\\_iPhone](https://en.wikipedia.org/wiki/History_of_iPhone)
- h. History of iPad - <https://en.wikipedia.org/wiki/iPad>